

**Universal UTV Wiper**  
**P/N: 12841 (12") and 13180 (16")**

**Installation Instructions:**

**Includes:**

1. Wiper Blade
2. Arm
3. Handle Assembly

**Tools Needed:**

1. 1/2" Drill Bit
2. 10 mm wrench
3. 17 mm wrench



Installation should be done by a certified technician.

**Installation:**

1. Install the wiper onto the wiper arm. You will have to pull open the plastic flap on the wiper by squeezing it. Then slide the arm onto the now exposed hairpin shape on the wiper. Now, close the flap.
2. Pick the location of your preference by holding the wiper in several locations.
3. Drill a 1/2" hole in your Hard Coat Polycarbonate Windshield.
4. Install the handle into the hole you just drilled using the 17 mm wrench.
5. Install the wiper/arm assembly on the the spindle using the 10 mm nut and wrench.

Note: This is a universal product so fitment may vary depending on your UTV and windshield.

