

UTV Dash Rocker Switch Kit


Product Instructions | Part No: 25-0700

Application: Verify accessory fitment at Kolpin.com.

Before You Begin: Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

Note: *This harness kit directly connects to Kolpin winch kits and accessories. If you have a non-Kolpin winch, you may have to splice wire connections.*

Note: *If any hardware is missing, do not return to the store. Call us to help, Toll Free 1-877-956-5746.*



This Kit includes:

Item	Qty	Part Description	Part Number
1	1	Dash Switch, Panel Mount	4015688
2	1	Vehicle Dash Switch-Contactor Harness	-
3	1	Instruction Guide (not shown)	-

Tools Required:

- Safety Glasses
- Drill or cutting tools for plastic

Assembly Time: Approximately 15 minutes

Important: Your Kolpin UTV Dash Rocker Switch Kit is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown. Additional time may be required to accommodate other installed accessories.

VEHICLE PREPARATION:

1. Shift vehicle transmission into "PARK". Turn ignition key to "OFF" position and remove from vehicle ignition.
2. Disconnect black negative (-) cable from battery first, then disconnect red positive (+) cable from battery.

UTV DASH MOUNT SWITCH INSTALLATION:

NOTE: *See the Electrical Connections Reference Guide section of the instruction manual for detailed photo of each part and their respective connections.*

3. Install dash mount switch (item #1) to desired location on your dash. Check to see if your vehicle has marked rectangular predefined switch location and trim area out. If not, use the cut-out dimensions shown below to cut-out the switch location in your desired location. (See illustrations 1-1 and 1-2).





⚠ WARNING ⚠

ALWAYS disconnect black negative (-) cable from battery **FIRST**. Failure to do so will result in high current electrical arc, and may result in battery explosion if tool touches grounded frame. Death or serious injury may occur.

UTV DASH MOUNT SWITCH INSTALLATION


(continued):

4. Connect the dash mount switch (item #1) to the vehicle Dash Switch Harness (item #2). Connect green wire to the "Out" pin, red wire to the middle pin and black wire to the "In" pin as shown. (See illustration 1-3).
5. Insert the dash switch harness and switch assembly thru the panel hole as shown. The switch will clip into the dash panel. (See illustration 1-4).
6. Connect the white connector of harness (item #2) to the winch contactor harness.
7. Connect the red wire of harness (item #2) to the vehicle keyed power accessory.
8. Confirm that all wiring is correct.
9. Confirm that there are no exposed wires or terminals.
10. All loose wires need to be wrapped tight, and secured away from moving parts and heat sources.
11. Reconnect the main vehicle power cables and the winch power red (positive) and black (negative) cables to battery terminals at this time using original hardware.
12. With vehicle key in the ON position, check winch for proper operation.



SWITCH OPERATION:

When properly installed, the dash rocker switch allows you to operate the winch while seated in the vehicle. Proper switch operation is shown. (See illustration 1-5).



For additional assistance, please contact Kolpin customer service department at (877) 956-5746 or (763) 478-5800 or email customerservice@kolpin.com

Five Year Mechanical Limited Warranty and Three Year Electrical Limited Warranty

For the period of five (5) years from the purchase date, Kolpin will replace for the original purchaser, free of charge, any mechanical part or mechanical parts found upon examination by Kolpin to be defective in material, workmanship, or both. For the period of three (3) years from the purchase date, Kolpin will replace for the original purchaser, free of charge, any electrical part or electrical parts found upon examination by Kolpin to be defective in material, workmanship, or both.

All transportation costs incurred submitting product to Kolpin for warranty consideration must be borne by the purchaser. If Kolpin determines that the product must be returned to the factory for credit, please call 1-877-956-5746 for a Return Merchandise Authorization (RMA) number and shipping instructions.

This warranty does not apply to parts that have been damaged by accident, alteration, abuse, improper maintenance, normal wear, or other causes beyond the manufacturer's control. In order to protect you and your ATV, certain parts of the winch/plow system and/or hardware are designed to fail when the equipment is over-stressed. Parts that are lost due to loosening and improper maintenance are not covered under warranty. This warranty does not cover removal or reinstallation labor fees of the winch/plow system and related components.

Peripheral products such as engines, electric motors, and actuators may carry an original manufacturer's warranty. Most hardware is general in nature and is easily obtained locally. Be sure to replace with minimum metric class 8.8 specification.

Kolpin Outdoors, Inc.

www.kolpin.com

ELECTRICAL CONNECTION REFERENCE GUIDE:

Red wire: To be connected to a power source that is energized when the key or ignition is turned ON.

